

Alaska Scientific Crime Detection Laboratory

DataMaster Evaluation Form

Effective: 11/10/2021

Version: 2.0

Instrument #: 100363

Analyst(s): Carlisle Claister

Start Date: 2/24/2022

Reason for instrument evaluation

Instrument went through certification & was used for Breath Test Supervisor Class. Screen froze multiple times

Visual Inspection

- | | |
|---|--|
| <input checked="" type="checkbox"/> Clean | <input checked="" type="checkbox"/> Replace missing screws |
| <input checked="" type="checkbox"/> Cermetex Box (modem) is secure | <input checked="" type="checkbox"/> Ensure modem cable present |
| <input checked="" type="checkbox"/> Double Check Valve secured to wall | <input type="checkbox"/> All tubing and connections secure |
| <input checked="" type="checkbox"/> O-ring inspection and ensure 2 replacement O-rings in bag | <u>connections to screen not secured.</u> |

all 2/24/22

Troubleshooting/Repair

Removed screen. Screen to be sent to factory for repair. No screens available at this time for replacement.

Add replacement screen when they arrive.

- | | |
|--|---|
| <input type="checkbox"/> VOC (attached) | <input type="checkbox"/> Verify software version |
| <input type="checkbox"/> VOC Internal Standard value $\leq 3.00\%$ | <input type="checkbox"/> Non-Drinking Subject Test (attached) |

all 2/24/22

- | | |
|---|--|
| <input type="checkbox"/> Return to Factory | <input type="checkbox"/> Ready for Calibration |
| <input type="checkbox"/> Ready for Certification | <input type="checkbox"/> Proceed to Close Out |
| <input checked="" type="checkbox"/> Further Evaluation Needed | |

End Date: 2/24/2022