

Alaska Scientific Crime Detection Laboratory

DataMaster Evaluation Form

Effective: 11/10/2021

Version: 2.0

Instrument #: 100416

Analyst(s): Carlisle Flaister

Start Date: 11/19/2021

Reason for instrument evaluation

Instrument returned from training @ APD

Visual Inspection

- | | |
|---|---|
| <input checked="" type="checkbox"/> Clean | <input checked="" type="checkbox"/> Replace missing screws |
| <input checked="" type="checkbox"/> Cermetex Box (modem) is secure | <input checked="" type="checkbox"/> Ensure modem cable present |
| <input checked="" type="checkbox"/> Double Check Valve secured to wall | <input checked="" type="checkbox"/> All tubing and connections secure |
| <input checked="" type="checkbox"/> O-ring inspection and ensure 2 replacement O-rings in bag | |

Troubleshooting/Repair

Screen is broken upon return & is inoperable
Unable to obtain VOC or non-drinking subject
test.
Screen needs to be replaced.

- | | | |
|---|--|-------------------------------|
| <input checked="" type="checkbox"/> VOC (attached) | <input checked="" type="checkbox"/> Verify software version | Not Applicable ckg |
| <input checked="" type="checkbox"/> VOC Internal Standard value $\leq 3.00\%$ | <input checked="" type="checkbox"/> Non-Drinking Subject Test (attached) | 11/23/2021 |

- | | |
|---|--|
| <input type="checkbox"/> Return to Factory | <input type="checkbox"/> Ready for Calibration |
| <input type="checkbox"/> Ready for Certification | <input type="checkbox"/> Proceed to Close Out |
| <input checked="" type="checkbox"/> Further Evaluation Needed | |

End Date: 11/19/2021